















### PARTS LIST

<p>1 2 PCS</p>  <p>LEG ASSEMBLY 1500E</p>	<p>2 2 PCS</p>  <p>TOP RAIL 1500T</p>	<p>3 4 PCS</p>  <p>BOTTOM RAIL 1500B</p>	<p>4 1 PCE</p>  <p>1500 x 1500 BENCH TOP</p>	<p>5 12 PCS</p>  <p>M10 CROSS PIN FOR BENCH</p>	<p>6 4 PCS</p>  <p>ADJUSTABLE FOOT</p>
<p>7 12 PCS</p>  <p>BUTTON HEAD SCREW M10 x 100</p>	<p>8 4 PCS</p>  <p>FIXING SCREW T17 x 30 FOR BENCHTOP</p>	<p>9 8 PCS</p>  <p>FIXING BRACKET SCREW 10G x 16 FOR BENCHTOP</p>	<p>10 4 PCS</p>  <p>BRACKET FOR BENCH TOP FIXING</p>	<p>11 1 PCE</p>  <p>6mm HEX BIT FOR FRAME ASSEMBLY</p>	




### STEP 1




SCREW THE ADJUSTABLE FEET (7) INTO THE PRE-DRILLED HOLES IN THE BOTTOM OF THE LEGS (1)

## STEP 2



Joining the leg assemblies.  
Start with single bottom rail (as shown)




SIDE VIEW

Cross Nut

Bolt


Insert the cross nut into the rail and thread the bolt through the leg frame into the cross nut. Keep these bolts loose until all the other rails are installed.

## STEP 3



Repeat procedure for remaining rails.


## STEP 4



### PRO TIP


Ensure the cross nut is facing dome-side out.

## STEP 5



Screw angle brackets into the leg frame on the inner top frame, using the metal self drilling hex head screws.

## STEP 6



**Screw the benchtop to the frame using the timber hex head screws**  
Screw the benchtop to the frame by screwing through the angle brackets into the bottom of the bench.  
Remember to centre the benchtop to the frame.  
The benchtop is heavy. You will need another person to assist.