


# ASSEMBLY INSTRUCTION

**MODEL: KUBE2-W-1800**












1800 x 900mm 2 Student Workbench




WOODWORK




## PARTS LIST

|   |  |  |   |   |   |
|---|--|--|---|---|---|
| <p>1 2 PCS</p>  <p>LEG ASSEMBLY<br/>900E</p>            | <p>2 2 PCS</p>  <p>TOP RAIL<br/>1800T</p>                     | <p>3 3 PCS</p>  <p>BOTTOM RAIL<br/>1800B</p>                          | <p>4 1 PCE</p>  <p>1800 x 900 BENCH TOP<br/>1800T</p>   | <p>5 10 PCS</p>  <p>M10 CROSS PIN FOR<br/>BENCH</p>        | <p>6 4 PCS</p>  <p>ADJUSTABLE FOOT</p> |
| <p>7 10 PCS</p>  <p>BUTTON HEAD SCREW<br/>M10 x 100</p> | <p>8 4 PCS</p>  <p>FIXING SCREW T17 x 30<br/>FOR BENCHTOP</p> | <p>9 8 PCS</p>  <p>FIXING BRACKET SCREW<br/>10G x 16 FOR BENCHTOP</p> | <p>10 4 PCS</p>  <p>BRACKET FOR BENCH<br/>TOP FIXING</p> | <p>11 1 PCE</p>  <p>6MM HEX BIT FOR<br/>FRAME ASSEMBLY</p> |   |




## STEP 1




SCREW THE ADJUSTABLE FEET (7) INTO  
THE PRE-DRILLED HOLES IN THE BOTTOM  
OF THE LEGS (1)

## STEP 2



Joining the leg assemblies. Start with single bottom rail (as shown). PLEASE NOTE the bottom rail can be fixed in any of the 3 positions (as seen in step 6).




SIDE VIEW

Cross Nut

Bolt

Insert the cross nut into the rail and thread the bolt through the leg frame into the cross nut. Keep these bolts loose until all the other rails are installed.

## STEP 3




Repeat procedure for remaining rails.




### PRO TIP

Ensure the cross nut is facing dome-side out.

## STEP 4




## STEP 5



Screw angle brackets into the leg frame on the inner top frame, using the metal self drilling hex head screws.

## STEP 6



**Screw the benchtop to the frame using the timber hex head screws**  
Screw the benchtop to the frame by screwing through the angle brackets into the bottom of the bench.  
Remember to centre the benchtop to the frame.  
The benchtop is heavy. You will need another person to assist.